

# 30cm Induction Cooktop




---

## FEATURES

2 Cooking Zones, Front Touch Controls,  
9 Power Levels, Residual Heat Indicator, 99 Minute Timer,  
Child Lock, Durable Ceramic Glass

# Congratulations on your new InAlto 30cm Induction Cooktop!

## THE CONTROL PANEL



## LEGEND

1. ON/OFF control
2. Power/Timer regulating controls
3. Heating zone selection controls
4. Timer control
5. Lock control

## USING YOUR COOKTOP

### To start cooking:

- Touch the "ON/OFF" control and all the indicators will show "--".
- Make sure the bottom of the pan and the surface of the cooking zone are clean and dry. Then place a suitable pan on the cooking zone that you wish to use.
- Touch the heating zone selection control for your desired zone. The indicator will flash.
- Select a heat setting by touching the "-" or "+" button controls. The options range from 0-9. You can modify this temperature at any time during cooking. If you don't choose a heat setting within 1 minute, the induction cooktop will automatically switch off. You will need to repeat the previous steps.

### To end cooking:

- Turn the whole cooktop off by pressing the "ON/OFF" button.
- Alternatively you can select your desired zone and use the "-" or "+" button controls to change the temperature of this zone to zero "0". After a cooking zone is turned off, the corresponding indicator will show "H" until the zone has cooled to a safe temperature.

Note: For further operation instructions refer to pages 10–12 of your user manual.

## DETAILS

Dimensions (W, D, H mm): 288 × 520 × 56  
 Built-in Dimensions (W, D mm): 268 × 500  
 Warranty: 3 Years (2 + 1 on registration)

## SUPPORT

Telephone: 1300 11 4357  
 Email: support@residentiagroup.com.au