

7kg/4kg Combo Washer Dryer




FEATURES


7kg Washing Capacity, 4kg Drying Capacity,
LED Display Screen, 1 Hour Wash & Dry Function, Delay Start,
15 Programs, Child Lock, Drum Clean Program

Congratulations on your new InAlto 7kg/4kg Combo Washer Dryer!


USING YOUR NEW WASHER DRYER




Plug in




Open tap




Load




Close door




Add detergent



Select program



Add any additional
functions required



Press Start/Pause to
start the program

For detailed operation instructions refer to your User Manual Pages 11–16.

BEFORE FIRST USE

Before using your dryer for the first time.

- Ensure the appliance is correctly installed as per the installation instructions in your User Manual pages 8–9.
- Leave the appliance to stand for 2 hours after transportation.
- Ensure you have checked the washing and drying care instructions for your clothing and your detergent use instructions before washing.

DETAILS

Capacity (Washing/Drying): 7kg/4kg
Dimensions (W, D, H mm): 595 x 565 x 850
Warranty: 2 Years

SUPPORT

Telephone: 1300 11 4357
Email: support@residentiagroup.com.au

REGISTER YOUR APPLIANCE

AU: www.inalto.house/registration
NZ: www.inalto.house/nz/registration