

46 Bottle Dual Zone Wine Cellar



FEATURES


Internal LED Lighting, Triple Glazed Glass Door,
Dual Zone, Touch Key Control Panel,
Wooden Shelves

Congratulations on your new InAlto Dual Zone Wine Centre!


INSTALLATION

The appliance is designed to be built-in, recessed or free standing installation.

The minimum space required is:
830H x 615W x 605D (mm)



For a complete guide, refer to user manual, page 10.



THE CONTROLS

Your Wine Cellar Centre Controls

- 1 Power Button**
Press and hold the power button for 6 seconds to switch the beverage centre on and off.
- 3 Upper Zone “+” Button**
Press to increase the set temperature shown on the display.
- 4 Upper Zone “-” Button**
Press to decrease the set temperature shown on the display.
- 3 Lower Zone “+” Button**
Press to increase the set temperature shown on the display.
- 4 Lower Zone “-” Button**
Press to decrease the set temperature shown on the display.
- 6 Light Button**
Press to turn the internal light on and off.

For a complete guide, refer to user manual, page 9.

DETAILS

Size (mm):
820–880H x 595W x 575D

SUPPORT

Telephone: 1300 11 4357
Email: support@residentiagroup.com.au